

★★★★ Smart Count

★★★ Fast Count

★★ Basic Count

★ Simple Weighing



Easy to Use. METTLER TOLEDO makes work easy with large, well marked keys and one key / one function use. The MonoBloc technology guarantees maximum accuracy and helps you to increase your productivity. The bright display offers you % accuracy and % capacity indicators. A built-in battery option allows you to use the scale wherever it is needed.



MonoBloc Inside. Heavy duty aluminum alloys, as used in the aircraft industry, assure high accuracy of measurement results for years to come. Because of the high resolution even for high capacities, with a Viper MonoBloc scale you have no need for a two scale system.

Rugged Quality. This leading counting scale features durable die-cast aluminum housing with stainless steel weighing pan and adjustable feet. Designed with the industrial environment in mind, it features no edges or grooves for easy cleaning!

Viper MonoBloc Precision Counting That Counts For You

METTLER TOLEDO



Viper MonoBloc Fast Count

MonoBloc Features:
 Long-term Stability
 Temperature Tolerant
 High Resolution
 Repeatability
 Linearity

- MonoBloc Load Cell for Highest Resolution
- Hands Free Counting / Operator Prompting Lights
- % Accuracy and % Capacity Indicators
- Rugged Die-Cast Aluminum Housing / RS232
- Fast LCD with back-light Display
- Zero, Tare, Print, Units, Clear, Scale Select, Sample, Sample Size, Info
- Numeric Keypad, Accumulation, ID, Hand Tare, Piece Weight
- Internal resolution up to 1 : 15'000'000

Small Chassis



Large Chassis



Model	Viper MB PD 3	Viper MB PD 6	Viper MB SD 12	Viper MB SD 30
Maximum Load	6lb / 3kg	12lb / 6kg	24lb / 12kg	60lb / 30kg
Default Resolution/ Readability	0.00002lb 0.00001kg	0.0002lb 0.0001kg	0.0002lb 0.0001kg	0.0002lb 0.0001kg
Repeatability	0.00002lb 0.00001kg	0.0002lb 0.0001kg	0.0002lb 0.0001kg	0.0002lb 0.0001kg
Platform Size (w x d)	6.5"x6.5" (165 x 165 mm)	7.9"x9.5" (200 x 240 mm)	9.5" x 13.8" (240 x 350 mm)	
Footprint (w x d x h)	10.3" x 12.6" x 4.2" (262 x 320 x 107 mm)		14.3" x 14.2" x 4.6" (363 x 361 x 117 mm)	
Actual Weight	13.2lb / 6.0kg		26lb / 11.8kg	
Shipping Size (w x d x h)	18.9" x 16.6" x 10.3" (480 x 420 x 260 mm)		20.7" x 20.9" x 10.7" (525 x 530 x 270 mm)	
Shipping Weight	15.8lb / 7.2kg		28.9lb / 13.1kg	

Built in Options (Factory Installed)

- Long life battery pack - lasts 30 hours
Battery Weight 1.46lb/0.6kg
- Additional RS232 interface

Accessories

- Printer
- In use cover
- Interface Cable

Mettler-Toledo, Inc.
 USA and Canada
 1900 Polaris Parkway
 Columbus, Ohio 43240
 TEL. (800) 786-0038
 FAX (614) 438-4518

Internet
 www.mt.com

101-CT03367.0E

Specifications subject to change without notice ©2001 Mettler-Toledo, Inc.
 Printed on recycled paper and is recyclable. Printed in USA.

